


BELLE ÉPOQUE





Assiette de présentation
Underplate
Ø : 32 cm - 12.6"
Réf. 31370 354 0029



Assiette gastronomie
Large dinner plate
Ø : 29,5 cm - 11.6"
Réf. 31370 354 0022



Assiette à dessert
Dessert plate
Ø : 24,5 cm - 9.6"
Réf. 31370 354 0007



Assiette à pain
Bread & butter plate
Ø : 16 cm - 6.3"
Réf. 31370 349 0010



Assiette creuse à aile
Rim soup plate
Ø : 28,5 cm - 11.2"
Réf. 31370 354 0130



Plat rond creux
Deep platter
Ø : 31,5 cm - 12.4"
Réf. 31370 128 0035



Plat rond plat
Flat dish
Ø : 31,5 cm - 12.4"
Réf. 31370 128 0031



Plat à tarte
Tart platter
Ø : 31,5 cm - 12.4"
Réf. 31370 111 0071



Plat ovale
Oval dish
L : 40 cm - 15.7"
l : 31,5 - 12.4"
Réf. 31370 301 0042



Ravier
Pickle dish
L : 23 cm - 9"
l : 16,4 cm - 6.4"
Réf. 31370 128 0065



Baker
Vegetable dish
L : 23,6 cm - 9.2"
l : 18,5 cm - 7.2"
Réf. 31370 301 0078



Plat à cake
Oblong cake platter
L : 39 cm - 15.4"
l : 15,5 cm - 6.1"
Réf. 31370 349 0073



Saladier
Salad bowl
200 cl - 67.6"
Ø : 26 cm - 10.2"
Réf. 31370 349 0053



Bol à céréales
Cereal bowl
25 cl - 8.4 oz
Ø : 14 cm - 5.5"
Réf. 31370 349 0055



Sucrier
Sugar box
30 cl - 10.1 oz
Réf. 31370 123 0421



Tasse & soucoupe café
Coffee cup and saucer
9 cl - 3 oz
Ref. 31370 301 0361



Tasse & soucoupe thé
Teacup and saucer
16 cl - 5.4 oz
Ref. 31370 301 0370



Théière
Teapot
55 cl - 18.5 oz
H : 13,5 cm - 5.3"
Réf. 31370 450 0410



Crémier
Creamer
26 cl - 8.8 oz
Réf. 31370 450 0430